



INSTELLEN WIRELESS (BLUETOOTH) BARCODE SCANNER SYMBOL LS4278

1. Full Reset (Set Defaults)



2. Instellen Carriage Return (ENTER na scan)



3. Emulate Keypad (zodat de cijfers altijd correct worden getypt, ongeacht de stand van Caps Lock)

